

DURA-PUMP™ QUICK CADDY

Recirculation Assembly Guide

DP 4000 Series • DEF 2000 Series • PM 1000 Series

ATTENTION

Apply an even coat of Thread Sealant on male threads. Hand tighten joints and torque another 1/2 to 3/4 turn until threads are sealed.


Congratulations on your recent Dura Products purchase.
This guide will take you through the steps to easily assemble your device.

Contents:

- A (1) 1" Nipple
- B (2) 1" Poly Street Elbow
- C (1) 1" Check Valve
- D (1) 90° Hose Barb
- E (1) 1" x 8" Hose
- F (2) 1" Hose Clamps
- G (1) 1" Hose Barb
- H (1) 1" Ball Valve
- I (1) 1" Male Cam Lock
- J (1) 2" x 1" Bushing
- K (1) 1" Female Cam Lock

Tools Required:

1. 5/16 Wrench or flat head screwdriver
2. Pipe thread sealant
3. WD-40 (optional)



Mount the Dura-Meter™ at the pump. (see illustration 1)

Step 1: Remove the 1" plug from back port of the Dura-Meter™ and thread **A** into back port, then thread **A** into discharge side of the pump.

Step 2: Thread **B** into right "OUT" port of the Dura-Meter™

Step 3: Thread **C** into **B**, then thread discharge hose into **B**

Step 4: Thread **D** into left port of the Dura-Meter™ and tighten with the female threads facing the center of tank

Step 5: Slide **E** onto **D** and tighten **F**

Step 6: Slide **G** onto opposite end of **E** and tighten **F**

Step 7: Thread **H** onto **G**

Step 8: Thread **B** into **H**

Step 9: Thread **I** into **B**

Step 10: Take out the 2" plug in the 6" Cage Tank Lid and thread **J** into the Tank Lid and thread **K** into **J**. Make the final connection with the cam locks.

Completed front and back views



DPAG_OCR_414



DURA PRODUCTS
Technology with Lasting Value

6660 East 266th Street, Suite 300 • Arcadia, IN 46030 • 1-855-502-DURA (3872) • www.DuraProducts.com

Dura Products, Inc.